

BESSEL

The logo for Bessel Studio Lighting features the word "BESSEL" in a bold, red, sans-serif font. Below each letter is a horizontal bar with a color gradient from red to yellow. Underneath these bars, the words "STUDIO" and "LIGHTING" are written in a smaller, black, sans-serif font, with the letters spaced out.

STUDIO LIGHTING

User Guide

Opening the softbox

Ensure the velcro edges on the body of the softbox are open, then with the metal speedring flat to the floor push down with even pressure on the ring around the centre stem.



Continue to push down until the locking pin clicks into place. Close the velcro straps on the body of the softbox.



Attaching the softbox to your lamp

The centre of the metal speedring will move freely to allow you to rotate the softbox when attached to your lamp. This movement is stopped by tightening the small thumbscrew located on the rim of the speedring. Ensure the thumbscrew is tightened when connecting the softbox to your lamp.



Align the metal speedring with the front of your lamp and attach in accordance manufacturer's instructions. Ensure the locking mechanism on your lamp is engaged after fitting. Attach the diffusers using the velcro fasteners on the inside of the softbox and the grid with the Velcro along the front edge of the softbox.

Closing the softbox

Remove the softbox from the lamp. With the metal speedring flat to the floor push down slightly with even pressure on the ring around the centre stem, this releases the tension on the locking pin. Push the locking pin in and allow the centre ring to move up.

